



NOTE:

1. ANYTHING 1:12 OR GREATER NEEDS TO BE FASTENED AT ANGLE CHANGE.
2. APPLY EVERGUARD[®] TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD[®] DETAIL 115).



www.gaf.com
1 Campus Drive,
Parsippany, NJ 07054



DRAWING #

112

SCALE
N.T.S.

CHANGE OF DECK PLANE DETAIL

THIS DETAIL APPLIES TO:
Adhered Systems
RhinoBond Systems
Mechanically Attached Systems

REVISION DATE
6-1-16